



Congratulations on your Precision Automated System. Please note, you can move the panels manually at any time when the panels and system are both unlocked.

Basic System Functions

- Open
 - Pressing “Open” will open the panels to the fully open position.
- Close
 - Pressing “Close” will close the panels to the fully closed position.
- Stop
 - Pressing “Stop” will stop the panels while moving open or closed.
- Lock/Unlock
 - Pressing “Lock/Unlock” will lock or unlock the panels. The lock indicator gives you the locking status.

Custom System Functions

- Motion-Open
 - With Motion-Open enabled, the open command is triggered by the interior and exterior motion sensors. When motion is detected, the lead panel will open 36”, wait for motion to clear and close behind you.
- Auto-Close
 - With Auto-Close enabled, the open command is triggered by the open button on the touchscreen and not the interior and exterior motion sensors. When the open button is pressed, the lead panel will open 36”, wait for motion to clear and close behind you.
- Auto-Lock | The system has three locking options:
 - Never – with the Auto-Lock on “Never,” the system will never automatically lock the panels. The system can only be lock/unlocked from the home page using the Lock/Unlock button.
 - Instant – with the Auto-Lock on “Instant,” the system will lock the door every time the system closes it. It will not lock if it is closed manually.
 - Daily – with Auto-Lock on “Daily,” the system will lock at the time specified daily.
 - If Auto-Lock is on daily, it will disable any other enabled feature at that time and lock your door.

Home Icon (top right of the screen)

- Pressing the home icon will take you to the home page.

Setting Icon (top right on the screen)

- Set Lead Panel
 - will allow you to adjust the lead panel opening distance in both Motion-Open and Auto-Close
 - Follow the touchscreen instruction after pressing the “Set Lead Panel” button to set.
- Set Time
 - the time clock is 24 hours.
- Reset
 - If the system is not fully opening or closing correctly, a reset should fix the issues.
 - Follow the touchscreen instruction after pressing the “Reset” button.